

BASE Configuration

COM5

CONN | CONFIG | TEST | LOADER | LORA | GPIO | TRANSP

NET

ID

UNIQUE ID

BaudRate

SENHA GRAVA SENHA SENHA VIA RF

Versão HW

Protocolo

FW VERSION

FW Revision

CHANNEL

SS

Cod Cliente

FWL

MEM SLOT

XtalTune

SYNC LEVEL

GW SYNC

TARGET ID

BaudRate

GW geral

LOCAL READ

REMOTE READ

WRITE CONFIG

COM5

CONN | CONFIG | TEST | LOADER | LORA | GPIO | TRANSP

ID

LORA PARAM

POWER LE LORA

BW PROGRAMA LORA

SF

CR FSK

CLASSE

CLASSE PROGRAMA CLASSE

JANELA VERIFICA CLASSE

Rover Configuration

COM6

CONN | CONFIG | TEST | LOADER | LORA | GPID | TRANSP

NET

ID

UNIQUE ID

BaudRate

SENHA GRAVA SENHA SENHA VIA RF

Versão HW

<input type="text" value="24"/>	MEM SLOT	<input type="text" value="0"/>	
Protocolo	<input type="text" value="0"/>	XtalTune	<input type="text" value="0"/>
FW VERSION	<input type="text" value="3"/>	SYNC LEVEL	<input type="text" value="0"/>
FW Revision	<input type="text" value="7"/>	Gateway	<input type="text" value="0"/>
CHANNEL	<input type="text" value="43"/>	TARGET ID	<input type="text" value="256"/>
SS	<input type="text" value="OFF/72k"/>	BaudRate	<input type="text" value="9600"/>
Cod Cliente	<input type="text" value="5"/>	GW geral	<input type="text" value="0"/>
FWL	<input type="text" value="2"/>		

LOCAL READ

REMOTE READ

WRITE CONFIG

COM6

CONN | CONFIG | TEST | LOADER | LORA | GPID | TRANSP

ID

LORA PARAM

POWER LE LORA

BW PROGRAMA LORA

SF

CR FSK

CLASSE

CLASSE PROGRAMA CLASSE

JANELA VERIFICA CLASSE